

SWR

Phase

Z=R+jX

Z=R||+jX

RL

TDR

Smith

RigExpert

Frequency, kHz

Limits

Center, range

Center

28 850

Range (+/-)

1 700

Points

100

Calibration

Full range

Run

Single

Continuous

Presets (center, range), kHz

Center

Range(+/-)

Points

Add

Delete

Move up

Measurements

Name


DK10

Open

Save

Delete

Clear



Settings

Export

Import

Print

Screenshot

Screenshot from AA

Data from AA